





TOP SPEED Up to 60 KMH / 37 MPH (offroad)



BATTERY RANGE 60+ KM / 55+ MI



TIRES 10" Tubeless Offroad Tires



MOTOR Dual 60V 1200W (2400W Total)



The Tsunami is an exciting new Dual 1200W (2400W total) electric scooter from Synergy. The Tsunami comes standard with our new 10" Tubeless Offroad Tires! Our Anti-theft voltage lock key and standard signal lights are added safety feature that take the Tsunami to the next level.

Make it yours! All Tsunami models include LED sidelights on the deck and upright. Download our app and choose from hundreds of different colour settings.

Suggested MAX weight of rider to be 250lbs

TECH SPECIFICATIONS

MOTOR	TIRES	SCOOTER DIMENSIONS - OPENED
Dual 60V 12 00W	10" x 2.75" Tubeless Offroad Tires	51.3" L x 8" W x 51.2" H (Inches)
(1200W in Single Mode / 2400W in Dual Mode)		130.5L x 20.5 W x 130 H (CM)
BATTERY 60V 24Ah Lithium Ion Battery	WATER RESISTANT Yes, this model is rated IP54. IP54 products are protected against water splash from all angles and heavy rain. If immersed fully in water, the product will be damaged.	SCOOTER DIMENSIONS - CLOSED 51.3" L x 8" W x 20.9" H (Inches) 130.5 L x 20.5W x 53H (CM)
TOP SPEED	GRADE ABILITY	LIGHTS
32 KMH / 20 MPH by display	25 to 30 Degree	Head light / Brake Light / Signal
Can be unlocked to 60 KMH/37 MPH for offroad use Check local regulations before unlocking		Lights / LED Sidelights on Deck and Stem (with App)
BATTERY RANGE	BRAKES	TEMPERATURE RANGE
Approx. 60km-90km. (37-56 mi)	Front and rear drum brake +	Working Temp: -5°C~40°C (14F-104F)
Range depends on many factors such as terrain, riders weight, riding style, dual or single mode	electric brake	Storage Temp: -5°C~40°C (14F-104F)
CHARGER	SUSPENSION	FOLDING MODEL
INPUT: 100-240V~50/60HZ OUTPUT: 67.2V===2.0A	Front and rear spring suspension	Yes, this model folds
CHARGE TIME	FRAME	ANTI-THEFT
10 hrs	Aluminum Alloy	Voltage Lock Key
SCOOTER WEIGHT	SPEEDOMETER	
40 kg / 88 lbs	Smart LCD display	RIDER MINIMUM AGE / SIZE RANGE 16 years old (between 150-215 cm)



BATTERY

The battery is the main energy source of your SYNERGY TSUNAMI, so be sure to treat it with care at all times. We recommend that your recharge it only with the charger provided with your SYNERGY TSUNAMI.

BATTERY FUNCTIONS

- 1. There are three key positions on, locked and unlocked.
- 2. When the key is turned to the **unlocked** position, the battery ready to be removed.
- 3. In the **locked** position (which can be found by turning the key one click from the unlocked position), the battery cannot be removed, and motor cannot be switched on.
- 4. In the **on** position (which can be found by turning the key two clicks from the unlocked position), you have full use of your bike's electronic components. When the key is in the **on** position, turn the motor and LCD screen on and off by pushing the power button on the display.